



JUST THE PATIENT

www.abloc.eu

Tel : + 33(0) 2 41 17 49 49

Fax: + 33(0) 2 72 22 11 43

info@abloc.eu

8 rue des Frères Montgolfier

49240 Avrillé

France



Instructions for use of the MEDEVAC mattress BRAN002ARM stretcher BRANSAC002 bag

Version v3 February 2025

The BRANSAC002 stretcher mattress bag BRAN002ARM provides waterproof protection for the mattress when rolled.

Restrictions on Use

- Do not use abrasive cleaners or scraper sponges.
- Prolonged use of alcohol or nail polish remover may deteriorate the bag shell

Features

- Made of a polyamide canvas coated with plasticized PVC: plasticized PVC 69% - Polyamide 6% - PU 2%
- Closure strap
- Traditional stitching assembly process

Dimensions :

- Bottom diameter 400mm
- Height 1000mm
- Flat width 620mm

Mattress rolling

To put the mattress in the bag, proceed as follows:

- Roll the mattress on the floor while compressing it.
- Belt the mattress with the strap provided with the mattress.



- Put the mattress in the bag.
- Roll up the top of the bag to make it waterproof.
- Close with the strap closure system with bag clips.



JUST THE PATIENT

www.abloc.eu

Tel : + 33(0) 2 41 17 49 49

Fax: + 33(0) 2 72 22 11 43

info@abloc.eu

8 rue des Frères Montgolfier

49240 Avrillé

France



Washing, disinfection and maintenance

- The mattress bag can be cleaned by wiping with a soft cloth dampened with water containing a neutral detergent or with a ready-to-use solution (e.g. ANIOS Surfa'safe, ALFAKARM Septalkan, HUCKERT'S Laboratory Umonium 38 Medical Spray...) or soaked wipes (e.g. ANIOS Oxy Wipes; Wip'ANIOS Excel; HUCKERT'S Umonium 38 Medical Tissues Laboratory...).
- In general, surface disinfectants containing a set of active ingredients such as aldehyde, quaternary compounds, guanidine derivatives and active oxygen, have proven their effectiveness. But always choose those formulated specifically for equipment, less film-forming and aggressive.
- In situ cleaning and disinfection can also be carried out on the coating with hot water by hand and a neutral detergent or with a sodium hypochlorite solution (0.1% or 1000 parts per million of available chlorine).
- Products such as Ercesolvent©, Remove©, GILBERT non-stick,© etc. used to remove adhesive residues (Elastoplast©, sticky drapes), should be thoroughly rinsed and dried immediately after use. Failure to do so may result in the buildup of reagent damaging the polyurethane coating. All products based on acetone, ether and other volatile solvents must be used with the same precautions.
- It is essential that items dry thoroughly after cleaning. Thus ,you should never put a mattress back in its bag before it has completely dried.
- Finally, for hygiene reasons, it is advisable to replace the bag if it shows damage (tear, cut, cracks, burns, etc.).

Special conditions of storage and use

Min temperature	Storage : -15 °	Use : +15°
Max temperature	Storage : +45 °	Use : +25°
Hygrometry (%HR) min	Storage : 30%	Use : 30%
Hygrometry (%HR) max	Storage : 70%	Use : 70%

End of life

At the end of its life, the bag must be placed in the system intended for the disposal of run-of-the-mill waste.

Any serious incident that occurs in connection with one of our mattresses must be notified to @bloc and the ANSM in accordance with the regulations in force.

For any further information, please contact us.

